



How do I	Steps to perform
<p><b>1</b> Secure the embedded Web server</p>	<ul style="list-style-type: none"> <li>a. Open the embedded Web server.</li> <li>b. Click the <b>Settings</b> tab.</li> <li>c. On the left side of the window, click <b>Security</b>.</li> <li>d. Type the password next to <b>New Password</b>, and type it again next to <b>Verify Password</b>.</li> <li>e. Click <b>Apply</b>. Make note of the password and store it in a safe place.</li> </ul>
<p><b>2</b> Gain access to Secure Disk Erase</p>	<p>Use HP Web Jetadmin to gain access to and set the Secure Disk Erase feature. For additional information about the HP Secure Disk Erase feature, see the HP support flyer or go to <a href="http://www.hp.com/go/webjetadmin/">http://www.hp.com/go/webjetadmin/</a>, click on the <b>Technical Whitepapers</b> tab and select the whitepaper titled 'Fleet Configuration in HP Web Jetadmin.'</p>
<p><b>3</b> Lock the control-panel menus</p>	<ul style="list-style-type: none"> <li>a. Open the HP Web Jetadmin program.</li> <li>b. Open the <b>DEVICE MANAGEMENT</b> folder in the drop-down list in the <b>Navigation</b> panel. Navigate to the <b>DEVICE LISTS</b> folder.</li> <li>c. Select the MFP.</li> <li>d. In the <b>Device Tools</b> drop-down list, select <b>Configure</b>.</li> <li>e. Select <b>Security</b> from the <b>Configuration Categories</b> list.</li> <li>f. Type a <b>Device Password</b>.</li> <li>g. In the <b>Control Panel Access</b> section, select <b>Maximum Lock</b>. This prevents unauthorized users from gaining access to configuration settings.</li> </ul>

